

RoofGuard AEC 606

Application Instructions

Preparation:

Broom sweep roof. Remove mildew with sodium hypochlorite or other algaecide and rinse with water. Tack down curled and lifted seams flush with the surface.

Fill any gaps with silicon impregnated latex caulk. Any loose pieces should be gently lifted and glued down with roofing cement.

Application:

The best method to assure good penetration of the first coat onto the surface is by the application with a 3/4 inch nap roller. The succeeding coats may be spray or roller applied.

Multiple thin coats are preferable to one thick coat.

Allow the coating to cure thoroughly before applying the next coat, 1 to 8 hours depending on wind, humidity and temperature conditions.

DO not apply if rain is imminent within four (4) hours after application or less than four (4) hours before the dew settles.

Estimated coverage for 20 mil thickness 2 gallons per 100 square feet